



**Application:**  
Lead Oxide

**Collector Model:**  
SPJ-168-X4T10

**Air Volume:**  
20,000 CFM

**Air-to-Cloth Ratio:**  
10.1 : 1

Contact Scientific Dust Collectors for more information. Ask for Application Number 091212.

## **Application Notes:**

Scientific Dust Collectors has numerous collectors, of assorted sizes, installed in battery manufacturing operations. The toxic nature of lead oxide requires HEPA “after filters” to be installed in the outlet of the collector. Scientific Dust Collectors accomplishes this by extending the clean air plenum and installing HEPA filters in this enclosure.